


**BSP-90****3450RPM****4" x 6"****G. P. M.**

20

40

80

100

120

140

**L. P. M.**

100

200

300

400

500

**No.****MODELO****HP****VOLT.****AMP.****FASES****ETAPAS****Ø DESC.**

1

BSP 90-05-5

3

200

2

BSP 90-08-75

7.5

200

2

10

1/2"

3

BSP 90-10-100

10

200

14

4

BSP 90-16-150

20

200

20

5

BSP 90-20-200

25

200

20